



MCD100™ USB Speakerphone

User Guide

Welcome

Congratulations on purchasing your new Plantronics product. This guide contains instructions for setting up and using your Plantronics MCD100 USB speakerphone.

The MCD100 is a high quality USB speakerphone that is optimised for use with UC audio applications. By default, the MCD100 utilises its internal microphone and loudspeaker providing high quality communication for all your VoIP applications.


Please refer to the safety instructions in the Quick Start Guide for important product safety information prior to installation or use of the product.

Contents


1 Package contents and features.....	4
1.1 MCD100 USB speakerphone	4
1.2 MCD100 USB speakerphone features	4
2 Set-up.....	5
2.1 Connecting USB speakerphone to PC	5
2.2 External speakers/headphones connection	5
3 Using your MCD100 USB speakerphone.....	6
Volume up, volume down, mute	6

1 Package contents and features

1.1 MCD100 USB speakerphone





Speakerphone



USB cable
(mini B to A)

1.2 MCD100 USB features


3.5 mm stereo jack
(for external speakers
or headphones)



2 Setup

2.1 Connecting USB speakerphone to PC

NOTE When the MCD100 is installed, it becomes the default audio device in your computer. You can set preferences manually in the Windows® operating system through the Sounds and Audio Devices option in the Control Panel.



- 1 Connect the USB cable to the USB port on the back of the speakerphone.**
- 2 Connect the other end of the USB cable to the USB port on your computer.** A blue light will illuminate through the buttons on the top of the unit indicating the speakerphone is powered on and operating.

2.2 External speakers/headphones Connection

The MCD100 is equipped with a 3.5 mm stereo headphones/external speaker connector. Connecting your computer's loudspeakers (or headphones) to the MCD100 will disable the MCD100 speakerphone's internal speaker. Your computer's audio (music, VoIP communication or any other) will be passed through to the external speakers, maintaining the same sound quality your computer can deliver. While the internal speaker is disabled when using this connection, the MCD100 speakerphone's internal microphone is still functional.

3 Using your MCD100 USB speakerphone

Volume up, volume down and mute

- 1 Press the down arrow (left button) to decrease the speaker volume.**
- 2 Press the up arrow (right button) to increase the speaker volume.**

NOTE A prolonged press of the volume buttons will increase or decrease the volume several levels until you stop pressing the button. The MCD100 will beep when a volume up button or volume down button is pressed and a series of beeps when a prolonged press is performed. Each beep signals one level of volume increase or decrease.

- 3 Press the microphone icon (middle button) to mute the microphone.** A blue light will flash indicating that the microphone is muted.
- 4 Press this button again to unmute.** The blue light will become solid indicating the microphone is unmuted.



Plantronics, Inc.
345 Encinal Street
Santa Cruz, CA 95060
United States
www.plantronics.com
For product support, contact us at www.plantronics.com/support.

© 2009 Plantronics, Inc. All rights reserved. Plantronics, the logo design, MCD100 and Sound Innovation are trademarks or registered trademarks of Plantronics, Inc.

81584-16 (05.09)